


How to change a sample with the gas-flow furnace:


1. Prepare the system for a sample change.
 - a. Stop gas flow by setting flow rates to 0 sccm and pressing the ON/OFF button for the appropriate gases on the AGES software.
 - b. If a hazardous gas has been flowing, ask instrument staff or IHC to complete the clean out routine.
 - c. Set temperature setpoint to 0°C.
 - d. Disable furnace alarm by pressing the button on the dashboard.
 - e. Turn off power to the heating elements by pressing the e-stop on the controller.

Sample temperature must be $\leq 100^{\circ}\text{C}$ before removing sample stick.

2. Remove the previous sample.
 - a. Carefully disconnect both thermocouple leads on the stick.
 - b. Disconnect the gas inlet and outlet hoses at the fittings from the stick.
 - c. Unscrew the compression fitting completely.
 - d. Carefully remove stick and hang from stick holder in the sample pit.
 - e. Scan sample with RadEye G radiation monitor. If it alarms, call the RCT (865-274-8658).
 - f. **Caution: Sample may be hot. Wear thermal gloves.** Free sample from stick by removing bottom pin.
3. Load new sample.
 - a. Hang new sample on stick using pin.
 - b. Carefully place stick into furnace.
 - c. Screw on compression fitting, keeping the gas fittings oriented correctly with the gas lines.
 - d. Reconnect the gas inlet and outlet hoses.
 - e. Reconnect both thermocouple leads, being careful to match the orientation marks.
4. Prepare the system for gas flow.
 - i. If a hazardous gas will be flowed, ask instrument staff or IHC to complete the clean out routine.
 - b. Open sample valve "111B" by clicking on the valve picture in the AGES software so that it is green.
 - c. Start gas flow by pressing the appropriate ON/OFF button and setting a flow rate on the AGES software.
 - d. Verify that the desired flow rates are being measured on the AGES software and that the expected results are seen in the RGA and pO2 sensor.
 - e. Re-enable furnace alarm by pressing the button on the dashboard.
 - f. After verifying that the setpoint is 0°C, twist the e-stop to release it.
 - g. Check that the furnace output power is on.



Furnace Alarm Enable/Disable



BL-11a Gas Flow Furnace Sample Change

